

www.procomvideosystems.com

# **User Manual**

85 Lancing Dr. Unit M Hamilton, Ontario L8W 2Z9 905-575-7223 Ver. 1.7.534854

# TABLE OF CONTENT

Overview	2
Chapter 1	
PROCOM VIDEO SYSTEMS Terminology	
Chapter 2	
Structure Pane	
Layouts	6
Layout Sequences	7
Digital PAN-Tilt-Zoom on live view	8
Digital PAN-Tilt-Zoom on Playback	8
Wizards	9
Chapter 3	10
How to Playback Video	10
Playback Window Structure	10
To Navigate through the Video	10
Fast forward, rewind	10
Smart Search	11
Define motion of interest –	11
Chapter 4	12
Backup Servers Archive Data	12
Export Snapshots	16
Notes	17
For Your Records	18

### **Overview**



**PROCOM VIDEO SYSTEMS** is a digital video recording and remote surveillance software package for Windows. PROCOM VIDEO SYSTEMS accepts video streams from all major Network (IP) cameras and servers, Frame Grabbers and any Direct Show compatible devices including Webcams and USB cameras. This along with the PROCOM VIDEO SYSTEMS client-server architecture allows you to build fully scalable solution sizing from a single camera up to thousands of cameras.

### **PROCOM VIDEO SYSTEMS** was designed to primarily be used to:

- 1. View live video streams from multiple sources locally and remotely, over the Internet.
- 2. Record video from multiple sources and play them back later locally or remotely
- 3. Export previously recorded video to preserve it and to present it as evidence.

**PROCOM VIDEO SYSTEMS** offers a principally new concept for DVR solutions – "One Software/Choice of Hardware". PROCOM VIDEO SYSTEMS DVR software can be either integrated with supported hardware or acquired from a PROCOM VIDEO SYSTEMS reseller as a part of a complete digital video recording and remote surveillance solution.

# **Chapter 1**



The icons perform functions which are explained below. It is possible to move these icons or make them disappear. Use your mouse to arrange the icons.

Each of the panes on the screen can be closed by left clicking on the "x" in the top right corner of the pane.

# PROCOM VIDEO SYSTEMS Terminology

Pane - Panel, window. i.e. Structure pane, event pane, and PTZ control pane.

PROCOM VIDEO SYSTEMS Icons-



### **Toolbar**

**Toolbar**- The toolbar that you see at the top of your screen gives you various options such as open, save and various screen manipulations, at the click of a button.



<u>Open Configuration-</u> This button on the toolbar allows you to open previous PROCOM VIDEO SYSTEMS configurations. It is most useful if you are exporting configurations from one machine to another.



**Save Configuration-** This button on the toolbar allows you to save any changes that you have just made to your DVR, it will continue to save to the same file unless you click on *File* and *Save* As then you can save to a different file or even to a floppy.



**Structure Pane**- This button toggles whether you see or don't see the *structure pane* on the left side of your PROCOM VIDEO SYSTEMS window. The *structure pane* is most useful when you are looking at cameras from multiple locations and multiple PROCOM VIDEO SYSTEMS servers. We will discuss the *structure pane* later on in this chapter.



**Events** - This button toggles the events window. The events window gives you important notifications such as, when you are connecting to a server successfully. It lets you know if you have input improper user names and passwords and gives you error codes when needed.



**PTZ Control**- This button toggles the PTZ control pane. If you do not have a pan-tilt-zoom camera connected to your system then this button does no need to be pressed.



**Video amplification**- This button toggles the video amplification pane. When this button is pressed a pane will come up from which you will be able to adjust the brightness, contrast, saturation, sharpness, and hue for any camera.



**Audio**- This button toggles Audio pane control. Audio pane enables you to listen to Audio from different cameras



**Full Screen**- This button toggles full screen mode. In full screen, none of the panes will be seen and the cameras will be expanded to their maximum size to fill the full screen of your monitor.



**Open Archive** – This button opens archive viewer window. You will be able to view archived data of your connected DVR



**Manage Maps** – This button toggles map module window for managing and viewing cameras on Google or previously added maps.



**Save Current Frame as** – This button allows you to save currently rendered video frame into file. Frame from selected screen will be saved only.



*Wizards*- The wizard's icon on the toolbar gives you a shortcut to various server, camera options and configurations. You can also access these features through the right click menus in the software.



**Views-** These buttons on the toolbar allow you to manipulate your views and camera layouts to your own preference.



**Screen Footer**- The screen footer button on the toolbar allows you to display various information underneath each camera window. It can display frame rate, time, picture quality, recording, motion detection, and image size. The screen footer is the text below each camera



**Stream Selection**- The stream selection button allows you to pick which camera you would like to view in the selected camera window. This can also be done through the right click menus and by dragging the desired camera from the structure pane to the desired display window, or right click on any camera window and select stream.




**Show Motion**- The show motion toolbar button toggles whether or not you want the motion outlined on the selected camera screen. Note: Motion detection must be setup before this feature can be activated.



**Maximize**- When pressed the maximize button puts the selected camera into a single view, if pressed again it will return to the previous view. This can also be accomplished by double clicking on the camera of choice.

# Chapter 2

# **Structure Pane**




The structure pane is the control centre of your DVR. It lists the server(s), cameras, archive cameras and Layouts set up on the DVR. Right click on the word layouts to create customized layout which will be discuss later in this manual.

# Bring a camera to full Screen

In the live view you can double click on any camera in your layout to bring it to full screen. To return the image to its original layout position, double click on the full screen image.

From the structure pane you can left click on a camera title and drag it over to the layout and drop it into a box. This will place the camera in that location on the screen.

## **Layouts**




Individual Layouts can be activated by double-clicking on them with the mouse.


Users now can perform playback and other function by right-clicking on the camera of their interest.

# **Layout Sequences**

When Layouts are created, they can be used for sequencing. To create sequences right mouse click on Layout Sequences.



# **Digital PAN-Tilt-Zoom on live view**



Right-Click on any camera to activate the Digital Pan-Tilt & Zoom (PTZ) function.

By activating the PTZ control pane live streaming video can be digitally enhanced.



# **Digital PAN-Tilt-Zoom Tools**


- **Default Tool** default mouse behaviour, it will click and drag as no digital PTZ was enabled. Digital PTZ control can still be accessible via PTZ control pane.
- **Drag Tool** when selected the mouse can drag a digitally zoomed image around the screen changing your viewpoint. Additionally, the mouse wheel will work the zoom in/zoom out functions.
- Zoom In/Out Tools digital zoom in or out using left button on the mouse when this tool is selected.
- Zoom Out to Full Frame zoom level automatically reverts to full screen image.

# **Digital PAN-Tilt-Zoom on Playback**

To activate the Digital PTZ function on already recorded video, just click on the PTZ icon control pane in the archive window. It can be controlled via PTZ control pane or mouse.

# **Wizards**

**PROCOM VIDEO SYSTEMS** DVR is a windows based application which has many different ways to perform the same tasks. In this User Manual we will explain one method only for simplicity.



# **CHAPTER 3**

# **How to Playback Video-**

To playback recorded video
Select the "wizards" icon.
From the menu select "Open Archive"

### You can also:

Right click on any camera view and choose open archive.

Your archive pane will now open




# Playback Window Structure-

Now that you are in the playback screen, the structure pane on the left lists all of the cameras that you have recordings for.

### To Navigate through the Video -

Double click on the camera you wish to playback (This camera will now appear with footage on the video screen)

The solid **green line** on the bottom represents time. The **light green lines** represent recorded video. The **orange lines** represent motion information.



There are basic VCR controls on the bottom of the playback screen, which you can use to play, pause, forward, and rewind.

RClient Archive

### Fast forward & Rewind

You have a jog dial on the bottom of the screen, which you can drag in either direction to browse through your video in high speeds.

Another way to fast forward is to use the arrow controls on top of the screen in which you can select increments of time in which you would like to move through the video.

Playback Motion Only-

Located at the top of your Archive Pane, there are two buttons that allow you to seek video with actual motion saving you time.

With the camera you wish to review.


Choose either: "seek previous motion"


or "seek next motion"



### Smart Search-

You can also search through video not only by motion in the screen, but also by **motion in a specific part of the screen**. Through Procom Video's playback screen, you can define a specific object in your view, or define a path, and seek through motion only in that specific region. This process is commonly referred to as "smart search".





Click on "seek to previous motion" or "seek to next motion" to search through motion in the defined grid(s).

# Chapter 4

Icon

data."

# Back Up Server's Archive Data

Select "wizards"

Then select "Backup

server's archive



Create, configure or delete server user and permissions...

Automatically discover network video devices and connect them to the server...

Submit a problem report to the LuxRiot DVR technical support team.

Add, configure or delete camera device... Configure export of video frames...

Manage server watchdog settings... View or modify server recording properties... View or modify server TCP communication pro

Backup server's archive data...

Open server's archive...

The most common method to perform this task is to use the "wizards"


File View Server Video Tools Help

Udeo J. 192.168.1.209 back garden

PROCOM VIDEO SYSTEMS - DVR




The following introductory page will appear.




By checking the box "skip introduction page next time" this page will no longer appear.

### Click Next

The system will then scan all the hard drives for video footage. This process could take several minutes.




Once the scan is complete, all the available cameras will be listed. By default all cameras are checked to back up. Select the camera(s) you wish to burn.



Right click in this area. A menu will appear to allow you to "Mark All" or "Unmark All" the cameras. This will save time if you don't want to burn all the cameras.


### Click Next



This page will appear on the screen it is defaulted to the correct setting. Simply, click next.

### Click Next


On this page you select the time and date of the event you wish to burn.



This box shows the estimated size of the back-up you are about to make. A CD-R will hold 700mb of information. A DVD-R will hold 4.7gb of information. If the back-up size exceeds the space available you will be asked to insert another disc. Please note that if you try to burn too much information the system may present an error. If this happens you will need to break up the burn into smaller time frames.

### Click Next


Select the destination of the burn. The default is to record to a CD/DVD.



Again, this shows you the estimated back up size.

### Click Next

On this page you select the CD/DVD Drive settings. Check the settings carefully.




If the system is running Windows 7 this box will read like this. If the system is running Windows XP this box must read "Nero Burning ROM" Use the drop down arrow to select.


This box must refer to a "Drive letter" as shown. If it reads "Image Recorder" use the drop arrow to select a drive location.

Ensure this box reads "eject disc drive"

### Click Next



When the burn is complete the disc will eject from the system and the following page will appear. This will indicate what was recorded and if it was successful.



Click Finish


### Export Snapshots.

Another way to export video is to save one frame at a time, like a snapshot.

First pause the video on the picture that you would like to copy,


Click on edit

Choose "save current frame as..."



Select the location in which you would like to save the snapshot.

It is recommended you purchase a USB flash drive to save snapshots to. This will allow you to easily transfer the image to a different computer or email.




# For Your Records Dealer Name: PROCOM VIDEO SYSTEMS Dealer Address: 85 Lancing Dr. Hamilton, Ontario L8W 2L6 905-575-7223 Date Of Purchase: Purchase Location: Hamilton, Ontario Software Activation Key: Dates Software Last Upgraded: www.procomvideosystems.com